

Air cart specifications

MODEL	3560	4460	4660	5560	5860	7660	9560
CAPACITIES							
Total	350 (12,234 L)	435 (15,329 L)	460 (16,210 L)	555 (19,558 L)	580 (20,439 L)	760 (26,782 L)	950 (33,477 L)
Tanks	2	3	4	3	4	4	4
Bin Split (bu)	160/190	140/105/190	140/105/190	190/105/260	190/105/260	230/170/325	325/170/420
Bin Split (L)	5638/6695	4933/3700/6695	4933/3700/6695	6695/3700/9162	6695/3700/9162	8105/5991/11453	11453/5991/14800
Small Seeds Tank Capacity bu (L)	NA	NA	25 (881)	NA	25 (881)	35 (1233)	35 (1233)
PRODUCT DELIVERY							
Product Delivery	Type B System - Primary division at meter and secondary division on seeding implement						
Meter Drive System	FlexRate Modular Metering System / Multi segment variable rate metering						
Fan System	Standard with two single fans for double shoot						
Sectional Control	Optional 10 run / expandable up to 12 run						
DIMENSIONS							
Height	189 " (4.79 m)	186 " (4.73 m)	186 " (4.73 m)	188 " (4.78 m)	188 " (4.78 m)	210 " (5.34 m)	210 " (5.34 m)
Height (With handrails down)	154 " (3.90 m)	154 " (3.91 m)	154 " (3.91 m)	160 " (4.05 m)	160 " (4.05 m)	188 " (4.76 m)	188 " (4.76 m)
Width	166 " (4.21 m)	221 " (5.62 m)	221 " (5.62 m)	221 " (5.62 m)	221 " (5.62 m)	233 " (5.90 m)	254 " (6.45 m)
Tow-Behind Weight	14,351 lb (6,510 kg)	16,330 lb (7,407 kg)	17,622 lb (7,993 kg)	18,289 lb (8,313 kg)	19,620 lb (8,899 kg)	21,494 lb (9,750 kg)	31,438 lb (14,260 kg)
FILLING SYSTEM							
Main Tank	10" Auger	Deluxe 10" Auger with remote control	Fast Fill Conveyor with remote control				
Small Seeds Tank	NA	NA	Pneumatic	NA	Pneumatic		

A dedicated dealer network

You're in the hands of a professional dealer network that provides the right advice and outstanding aftersales service and support. With almost 50 outlets across Australia, the Flexi-Coil dealer network is committed to supporting Flexi-Coil customers.

For further information
please call 1800 790 811 or
go to www.flexicoil.com.au

flexicoil
www.flexicoil.com.au

Equipment subject to local availability. Design, materials and/or specifications are subject to change without notice and without liability therefore. Specifications are applicable to units sold in Australia and may vary outside the region.

© CNH Industrial Australia Pty Ltd. All rights reserved.

Safety begins with a thorough understanding of the equipment. Always make sure you and your operators read the Operator's Manual before using equipment. Pay close attention to all safety and operating decals and never operate machinery without all shields, protective devices and structures in place.